

ACF-602N

Dual Channel 6 Fiber Antennas Combiner



Instructions

- > **Power** : 220V power supply
- > **Fiber optics** : Neutrik OpticalCon Duo APC or LC/APC fiber optics cables linked to Antenna Fiber Boxes (AFB-150, AFB-250 for Neutrik version and AFB-100, AFB-200 for SC version)
A1/B1, A2/B2 and A3/B3 inputs for duplex version
A1, A2, A3 and B1, B2, B3 inputs for simplex version
- > **RF out** : BNC outputs A and B to one or more wireless diversity receivers

LED Indications

- > **Power** : Green color lights up when the device is on
- > **Optical** : Green color indicates that optical link is active
Beyond 3 dB power loss in optical link, this LED will blink

